

Pan Mode
1st Press  Track Select  Marker  Select  Pan    2nd Press  Active Control  mode.  See  notes below.
Send Mode
Track Select Aux Level Aux Select
EQ Mode
Gain  Frequency  Quaity    Track < / >  Use Track to select band.
Track Select  Slot Select    Track >  Use Track   to page throug  h parameters
Auto Mode
Toggles mode between Read and last used.
Notes
Active Control - press PAN to toggle Active Control Mode. Fader controls selected on-screen element.
EQ - Use Track up/down buttons to select bands 1 through 4.
PLUG-IN - Use Track up/down buttons to page through parameters.
AUTO - toggles betwee